


KNOW YOUR CRANE SIGNALS



Note: When signalling you should stand in a safe position where you can see the load and can be seen clearly by the crane operator. Face the driver where possible. Each signal should be distinct and clear